

INSTALLING BI-FOLD DOORS

Step 1

Set the top pivot in the top hole on the pivot door and tap it into position with a hammer.

Step 2

Set the guide pivot into the hole on the guide door. Tap into hole with hammer.

Step 3

Locate the jamb bracket on the floor, so that it's in line with the track.

Step 4

Drill pilot holes in the jamb and the floor for installation of the jamb's bracket screws, now install the jamb bracket's with the screws.

Installing the doors

Step 1

Place the top pivot in the pivot hole, slightly lift the door and then seat the bottom pivot in the jamb bracket.

Step 2

Insert the snugger guide into the track, now depress the guide pivot to fit inside the track.

Step 3

Follow the instructions for adjusting the doors.